


Redline Seat Installation

Check List Prior to Installation

1. Quick Down/Auto Exit Hose Tie Down
2. Air Line Connection Guide
3. Electric Connection

AIR LINE CONNECTION GUIDE



EXHAUST HOSE
1/8" VERY THIN HOSE
DO NOT CONNECT!
MUST BE OPENED!

AIR IN HOSE
1/4" AIR HOSE
CONNECT AIR WITH THIS HOSE
RECOMMENDED PSI 120 PSI

Electric Connection

Electric connection is simple & easy steps to follow

1. Red line connect to Positive/Power
2. Black Line connect to Negative/Ground
3. Only connect with DC12V 10Amp
4. Below Red & Black wire to be connected



This is where you can find Red & Black wires